



Information1
Description and dimensions1
Phisical analisis
Graph: Static2
Assembly and versions3
Applications

La información contenida puede ser modificada sin previo aviso





#### Information

The PAD is the generic name of "double anti-vibration plate" as they are formed from two antivibration mats AD 412 (black), AD 412B (blue) or mixt of both. This makes that are obviously the same viscoelastic plates rubber used for the manufacture of the individual sheets in different grades and proportions.

PADs are used when the requirements of the point load are superior to AD and AD 412 or mouse 412B, or a greater level of effectiveness is required to prevent the passage of the vibratory transmission. As a consequence of these requirements, the PAD model is divided into two categories based on the geometry of its basis toothed Mouse (AD 412 and AD4 12B):

- The PAD 416, 416B and 416Mixt., Series are formed by two damped plates fitted by the toothed faces. The goal is to create a greater load which supports block and turn the discontinued created by the engagement of the teeth, that favours the vibration isolation.
- The PAD PAD 424 and 424B series are characterized by having an opposite position from previous models, because they are assembled by the smooth faces of the antivibration plates to hide the gear sides.
- So PAD 424 in both the upper and lower side is jagged but with opposites orientation. The justification is to create a mechanical system in series and therefore achieve a greater vibration isolation with the same capacity as a single plate damped.






PAD 230 and the PAD 230 B series are manufactured as PAD PAD 424 and 424B but with greater height to better accommodate large irregularities of the ground.

PAD 412 B

**PAD 416** 

**PAD 424** 



**PAD 230** 

FAX. 93 675 58 90 Email: vib

Email: vibcon@vibcon.es Web: www.vibcon.es

TEL. 93 583 61 08





#### Description and dimensions

	Dimensions (mm)			
Model	Α	В	С	Tooth type
AD 412	380	380	12	Trapezoidal
AD 412 B	380	380	24	Trapezoidal
PAD 416	388	388	16	Trapezoidal
PAD 424	388	388	24	Trapezoidal
PAD 230	194	198	33	Trapezoidal
PAD 430	388	388	33	Trapezoidal

# Dampened AD 412 mats can be assembled by its toothed face for greater load capacity, called PAD.

\* (See sheet pad 416 ft)



**PAD 416** 



**PAD 424** 

**PAD 230** 



TEL. 93 583 61 08

FAX. 93 675 58 90

Email: vibcon@vibcon.es





## Phisical analisis


Physical Properties	Value	
Material	Rubber (NR)	
Colour	Satin black	
Hardness [ºShA]	55	
Maximum load [daN]	23.000	
Maximum arrow [mm.]	3	5%
Minimum load [daN]	2500	5%
Minimum load [mm.]	1	
Optimal load [daN]	6000-16500	

**PAD 416** 



Physical Properties	Value	
Material / Colour	Rubber (NR) Blue	
Dampening factor	0.03	
Hardness [°ShA]	45	
Maximum effort [daN/cm²]	1,5	
Maximum arrow [mm.]	5.2	
Minimum effort [daN/cm²]	0.01	
Minimum arrow [mm.]	1	
Optimal pressure [daN/cm²]	0.2-1,7	

**PAD 424** 



Physical Properties	Value	
Material	Rubber (NR)+EVA	
Colour	Satin black / Grey inside	
Hardness [°ShA]	55	
Maximum superficial pressure [daN/cm²]	4.4	
Maximum arrow [mm.]	8	
Minimum superficial pressure [daN/cm²]	0.01	5%
Minimum arrow [mm.]	0.5	
Optimal superficial pressure [daN/cm²]	0.05 - 3.6	

**PAD 230** 



TEL. 93 583 61 08

FAX. 93 675 58 90

Email: vibcon@vibcon.es

2







**VIBROACÚSTICA** 

**Antivibrators** 


Rev.2 07/2015

#### Graph: Static









TEL. 93 583 61 08

FAX. 93 675 58 90

Arrow [mm]

Email: vibcon@vibcon.es







## Assembly ans versions





Prohibited its total or partial reproduction without prior authorization






**PAD 424** 











FAX. 93 675 58 90

Email: vibcon@vibcon.es


# Particular application of PAD 424 B

One case of applying the PAD 424B is illustated here, is applied in attenuating structural noise induced by the mechanical vibration generated by the pump and air compressor 100 l/min of an aquarium.

The aquarium capacity was of 360 liters and approximate dimensions of 120x60x50 cm., And was installed in a house (transmitter) and affecting the other bedrooms of the adjoining housing (receiver).


	Zone	*Level [dBA]
Transmitter house		46
Receiver house SIN PAD 424 B		26
Receiver hou CON PAD 424		19

Note \*: Levels corrected by background noise





Formed from 2 antivibration plates joined by their smooth and displaced face between both 90°






As can be seen, the most important specific attenuation at frequencies of 50 Hz and 100 Hz. Below 30Hz there is no attenuation.

Ref: PE-LEAM 45461115









# Zibcon®

Vibroacústica Control y Aislamiento S.L.

